

300M Compression Balljoint Installation

Instructions – Ranger

- 1) Remove nut from balljoint – Be aware the nut holds the locking dowel pin for adjustment screw in place (All come Pre-adjusted)
- 2) Press housing into A-arm
- 3) Make sure Pin is still locking the Adjustment screw into the housing & apply Blue Loctite to the threads of the housing.
- 4) Impact nut onto housing with the shoulder facing towards the boot using 36mm socket
- 5) On New Body Style Ranger Lower – Tighten lower Nylock nut to 38-40 ft lbs
- 6) Grease with a Moly-Graphite grease gun once installed on machine

