

300M Compression Balljoint Installation

Instructions

- 1) Unscrew balljoint cap from housing
- 2) Remove silver jam nut & back out adjustment screw
- 3) Install housing into balljoint plate & apply blue Loctite to threads of Housing
- 4) Screw Cap onto balljoint housing using an impact & 36mm socket.
- 5) Tighten adjustment screw snug against pin, then back off ¼ turn to allow slight movement of pin
- 6) Apply blue Loctite to adjustment screw & install silver jam nut
- 7) Make sure nut is snug onto the housing, but still allows pin to move freely
- 8) Grease with a Moly-Graphite grease gun once installed on machine

