



# Nightwatch Security & Telephone, L.L.C.

2211 West Main, Sedalia, MO 65301 • 660-827-3408 / 800-462-1996




## FIRE COMMAND SYSTEM TOUCHSCREEN FIRE DRILL INSTRUCTIONS

### Fire Drill Instructions

Generally fire drill sounds local alarms only and does NOT notify Nightwatch. We still recommend notifying Nightwatch in advance in case of any issues, or in case we do receive a signal.

1. Go to a phone and dial 827-2000 (1-800-827-3408) to call NIGHTWATCH CENTRAL, our alarm monitoring center. Ask them to put your system on test, give the operator your name and any other information requested.
2. Access the Keypad by scrolling through the Carousel Menu on the right side of the display.
3. Press CMD repeatedly until you see **"MENU NO YES"**. Press **YES**, then enter your user code or present prox key / card to the built in proximity card reader on top center of keypad, over the light. You are now in the menu.
4. Press CMD until **FIRE DRILL?** displays and select it.
5. The display will read **"SURE? NO YES"** Press **YES**. All fire sounders will immediately sound when you do this.
6. To end drill, enter your user code or present prox key / card to the built in proximity card reader on top center of keypad, over the light and press **CMD**.
7. Go to a phone and dial 827-2000 (1-800-827-3408) to call NIGHTWATCH CENTRAL, our alarm monitoring center. Ask them to put take your system off test, give the operator your name and any other information requested.



### NOTES:

1. After step 2, you are in the menu system. CMD moves to the next selection, ← (left arrow) moves to the previous selection.
2. If you normally press CMD when entering your code to arm the system, do so in step 2 also. This varies from system to system.
3. If you do not see the **"FIRE DRILL?"** option, your code may not be authorized to set the time. Have someone with a master code set the time.

NOTE: These are basic instructions, and do not cover all possible situations. If questions arise, refer to your users guide, or call Nightwatch Security & Telephone for assistance at 827-3408 (1-800-462-1996.)