



# Nightwatch Security & Telephone, L.L.C.

2211 West Main, Sedalia, MO 65301 • 660-827-3408 / 800-462-1996



## SECURITY COMMAND SYSTEM TOUCHSCREEN KEYPAD INSTRUCTIONS

### Arming a Home/Away System

1. Be sure that all protected doors/windows are closed; the exit door must also be closed. Everyone also must stand still to avoid tripping any motion sensors. The display should not have the **ATTENTION LIST** above the shield.

A. To arm system when not leaving, on the Main Screen, press the center of the Shield icon and release. This displays Home/Sleep/Away options. Press the **HOME** icon and hold until it glows.

If keypad displays **ENTER CODE:**. Enter your user code or present prox key / card to the built in proximity card reader on top center of keypad, over the light.

The Power/Armed LED light will then turn red and the system will then begin counting down.

B. To arm your system at night using the **SLEEP** option (if your system has it), on the Main Screen, press the center of the Shield icon and release. This displays Home/Away options. Press the **SLEEP** icon and hold until it glows.

If keypad displays **ENTER CODE:**. Enter your user code or present prox key / card to the built in proximity card reader on top center of keypad, over the light.

The Power/Armed LED light will then turn red and the system will then begin counting down.

C. To arm system to leave:

a. **If you have no prox key / card**, on the Main Screen, press the center of the Shield icon and release. This displays Home/Away options. Press the **AWAY** icon and hold until it glows.


If keypad displays **ENTER CODE:**. Enter your user code.

The Power/Armed LED light will then turn red and the system will then begin counting down and, if programmed to, the system will beep repeatedly until the countdown ends to remind you to exit the premises.

b. **If you have a prox key / card**, present prox key to the built in proximity card reader on top center of keypad, over the light.

The Power/Armed LED light will then turn red and the system will then begin counting down and, if programmed to, the system will beep repeatedly until the countdown ends to remind you to exit the premises.

Hold prox key / card here –  
built in proximity card




HOME = \_\_\_\_\_  
SLEEP = \_\_\_\_\_  
AWAY = All Sensors On

*Zone Faults & Disarming System on Back*

## Zone Faults

1. If after making your selection the display says that there is a zone fault, this usually means that a door is open, or a motion sensor has picked you up while arming the system.


The display will then show **OKAY BYPASS STOP**  
**Always select STOP.**



2. After the system displays **ARMING STOPPED** and goes back to **SYSTEM READY**, begin again with Arming Step 2; remember to stand very still while turning the system on so you do not trip a motion sensor.
3. If it indicates that there is a fault for a second time, please visually check the sensor indicated for problems.
4. As a last resort, you may choose **OKAY** to force the system to arm even though there is a problem, leaving the indicated area unprotected.

## Disarming a Home/Sleep/Away System

1. During entry delay, the keypad displays **ENTER CODE:**. Enter your user code or present prox key to the built in proximity card reader on top center of keypad, over the light.
2. The keypad next displays the home screen with a shield that says disarmed. It also says **ALL SYSTEM OFF** on the top right.
3. The keypad also displays any alarms or communication problems that occurred during the armed period by pushing the Attention List icon at the top.



*In the event that the display says **INVALID CODE**, wait 5 seconds until the **INVALID CODE** message disappears, and enter your code again.*

## Disarming During an Alarm

Use this procedure when your siren is sounding to cancel the alarm. You must cancel the alarm, and then immediately call our alarm monitoring center.

1. At any keypad, enter your code or present prox key to silence the alarm sounder. The display should read **'IS THIS A FALSE ALARM?'** select YES. The display should then read **ALARM CANCELLED**.

*(In the event that you do not want to cancel the alarm, select the **NO** option to let Nightwatch Central know that this is not a false alarm.)*

*If the display indicates **INVALID CODE**, wait 5 seconds until the **INVALID CODE** message disappears and enter your code again.*



2. Go to a phone and dial 827-2000 (1-800-827-3408) to call NIGHTWATCH CENTRAL, our alarm monitoring center. Give the operator the password, your name, and any other information requested so that we may cancel the alarm.

*If the phone rings before you have called Nightwatch Central, please answer. Our operator will say, "This is Nightwatch Central." At that point, you should respond with the password, your name, and let the operator know that everything is OK.*

**IMPORTANT:** *If you receive another call before speaking with Nightwatch Central, please excuse yourself and call Nightwatch Central immediately (see step #2). It is important that you cancel the alarm before authorities are notified.*

NOTE: These are basic instructions, and do not cover all possible situations. If questions arise, refer to your users guide, or call Nightwatch Security & Telephone for assistance at 827-3408 (1-800-462-1996.)